

Draft genome assembly using parasitic mite population NGS DNA sample from mites extracted from host wound environment Version 2

Mofiz E., Holt, D., Seemann, T., Currie B.J., Fischer K., Papenfuss A.T.

Abstract

This protocol is from:

Mofiz E. et al., [Genomic resources and draft reference assemblies of the human and porcine scabies mites, *Sarcoptes scabiei* var. *hominis* and var. *suis*](#). *GigaScience*. 2016. DOI: 10.1186/s13742-016-0129-2 <http://dx.doi.org/10.1186/s13742-016-0129-2>.

Citation: Mofiz E., Holt, D., Seemann, T., Currie B.J., Fischer K., Papenfuss A.T. Draft genome assembly using parasitic mite population NGS DNA sample from mites extracted from host wound environment. **protocols.io** dx.doi.org/10.17504/protocols.io.ez7bf9n

Published: 02 Jun 2016

Protocol

Step 1.

Sequence DNA sample in Illumina HiSeq generating paired-end data.

■ [DATASET](#)

● **Illumina HiSeq 2500 paired-end sequence data**

Step 2.

Assess read qualities of read files (fastq files) using FASTQC.

● [SOFTWARE PACKAGE \(Linux\)](#)

FASTQC

Step 3.

Trim fastq read files for adapter and quality ($Q \geq 20$).

● [SOFTWARE PACKAGE \(Linux\)](#)

Trim Galore! 

■ [ANNOTATIONS](#)

Richard Edwards 05 Jan 2018

The link to Trim Galore!

Step 4.

Download host genome (e.g. human hg19). Build Bowtie2 reference index of the host genome. Align adapter and quality trimmed reads to the host reference genome using Bowtie2 (using end-to-end mode and --very-fast parameters).

 [SOFTWARE PACKAGE \(Linux\)](#)

Bowtie2

 [DATASET](#)

 **host genome**

Step 5.

Extract unmapped paired reads using samtools view with -f 12 flag (read unmapped, mate unmapped)

 [SOFTWARE PACKAGE \(Linux\)](#)

SAMtools 

cmd [COMMAND \(Linux\)](#)

samtools view

Step 6.

Assemble paired-end unmapped reads using Platanus assembler (default settings). From the assemblies, filter out scaffolds that are less than 500 bp to get major scaffold assemblies.

 [SOFTWARE PACKAGE \(Linux\)](#)

Platanus

Step 7.

Download Microbial RefSeq Database from The National Center for Biotechnology Information (NCBI). Align Platanus scaffolds to the database using BLASTN (e-value cutoff 10^{-20} ; max_target_seqs 1). Filter for top hits and filter out scaffolds that have more than 80% of their length aligned to bacterial sequences. This gives you the draft assembly.

 [SOFTWARE PACKAGE \(Linux\)](#)

BLASTN

 [DATASET](#)

 **Microbial RefSeq Database from The National Center for Biotechno**