

Single Amplified Genome Assembly

Tyler Alioto

Abstract

Citation: Tyler Alioto Single Amplified Genome Assembly. **protocols.io**

dx.doi.org/10.17504/protocols.io.nccdasw

Published: 23 Mar 2018

Before start

Software pre-requisites:

Spades

SGA

cutadapt

trim_galore

Augustus

BUSCO

Data sources:

http://spades.bioinf.spbau.ru/spades_test_datasets/ecoli_sc/

<https://www.nature.com/articles/s41598-017-05436-4>

Get from the ENA if possible.

<https://www.ebi.ac.uk/ena/data/view/PRJDB5352>

<https://www.ncbi.nlm.nih.gov/bioproject/PRJDB5352>

E.coli reference

https://www.ncbi.nlm.nih.gov/nuccore/NC_000913

Protocol

Step 1.

Download datasets (or generate them if doing a real experiment!)

DATASET

 **E. coli reference genome** [↗](#)

Step 2.

Run pre-QC (SGA)

DATASET

 **SPAdes E. coli (single cell)** [↗](#)

cmd **COMMAND**

```
cat ecoli_mda.preqc | perl -
e 'while(<>){if (/FragmentSize/){my $line = <STDIN>;while(my $line=<>){if($line=~m/(\d+)/){
print '$1\n';}else{exit;}}}}' > ecoli_mda.frag sizes
```

```
module load R
R
#> frag<-read.table('ecoli_mda.frag sizes',header=F)
#> summary(frag)
#           V1
# Min.      : 52.0
# 1st Qu.: 257.0
# Median : 281.0
# Mean    : 259.9
# 3rd Qu.: 301.0
# Max.    :1246.0
#> quit()
Check insert size in R
```

Step 3.

Adapter and Quality Trim (trim_galore)

cmd **COMMAND**

```
trim_galore --gzip -q 10 --paired --retain_unpaired reads.1.fastq.gz reads.2.fastq.gz
Trim Illumina adapters and quality trim 3' bases less than Phred Q10
```

Step 4.

Determine composition / Identify genome if known (Kraken) if not already know from 16S RNA sequencing.

cmd **COMMAND**

```
kraken --db /path/to/kraken_db/kraken_abfpv_21_08_2016 --threads 4 --preload --fastq-
input --gzip-compressed --paired --quick --only-classified-output --
output ecoli_sdmda.kraken.out $ASSEMBLY/data/ecoli_sdmda.100k.1.fastq.gz $ASSEMBLY/data/ecoli_sdmda.100k.2.fastq.gz
```

Step 5.

Run SPAdes (optionally run ccSAG to do co-assembly of SAGs -- includes QC step 2)

ccSAG

<https://github.com/mstkgw/ccSAG>

cmd COMMAND

```
mkdir -p $ASSEMBLY/sags/spades_ecoli_mda
cd $ASSEMBLY/sags/spades_ecoli_mda
# IMPORTANT! make sure to turn on the single-cell mode with --sc
# Optionally add --careful
# Loading the environment with module load in the job script itself ensures the proper optimizations are used depending on which partition the job is run.
module purge; module load gcc/4.9.2 SPADES/3.5.0
spades.py --only-assembler --
sc -1 ${ASSEMBLY}/data/ecoli_mda.1.fastq.gz -2 ${ASSEMBLY}/data/ecoli_mda.2.fastq.gz -t 4 -o ecoli_mda_spades

mkdir -p $ASSEMBLY/sags/spades_ecoli_sdmda
cd $ASSEMBLY/sags/spades_ecoli_sdmda
module purge; module load gcc/4.9.2 SPADES/3.5.0
spades.py --
sc -1 ${ASSEMBLY}/data/ecoli_sdmda.1.fastq.gz -2 ${ASSEMBLY}/data/ecoli_sdmda.2.fastq.gz -t 24 -o ecoli_sdmda_spades

mkdir -p $ASSEMBLY/sags/spades_bsubtilis_sdmda
cd $ASSEMBLY/sags/spades_bsubtilis_sdmda
module purge; module load gcc/4.9.2 SPADES/3.5.0
spades.py --
sc -1 ${ASSEMBLY}/data/bsubtilis_sdmda.1.fastq.gz -2 ${ASSEMBLY}/data/bsubtilis_sdmda.2.fastq.gz -t 24 -o bsubtilis_sdmda_spades

mkdir -p $ASSEMBLY/sags/spades_soil_sdmda
cd $ASSEMBLY/sags/spades_soil_sdmda
module purge; module load gcc/4.9.2 SPADES/3.5.0
spades.py --
sc -1 ${ASSEMBLY}/data/soil_sdmda.1.fastq.gz -2 ${ASSEMBLY}/data/soil_sdmda.2.fastq.gz -t 24 -o soil_sdmda_spades
```

Step 6.

Determine completeness (CheckM and/or BUSCO)

cmd COMMAND

Assume you have putative genomes in the directory /home/donovan/bins with fa as the file extension and want to store the CheckM results in /home/donovan/checkm. To processes these genomes with 8 threads, simply run:

```
checkm lineage_wf -t 8 -x fa /home/donovan/bins /home/donovan/checkm
CheckM
```

Step 7.

(Optional) Align to Reference (MUMMER)

SOFTWARE PACKAGE (Linux)

Mummer

<https://github.com/mummer4/mummer>

cmd **COMMAND**

```
dnadiff -p query.v.ref ecoli_ref_NC_000913.3.fasta ecoli_mda_spades.fasta  
mummerplot --png out.delta
```