OPEN ACCESS

✓ protocols.io

Introduction to read mapping Version 2

Frank Aylward

Abstract

This is an example of a simple read mapping workflow. It is designed to be performed via the command line on an Ubuntu 16.06 OS.

After completing this tutorial you should:

- 1) Have a practical understanding of how read mapping analyses are performed in the command line.
- 2) Understand the basics of how to process SAM and BAM files.
- 3) Be able to calculate depth of coverage of a contig/scaffold/chromosome in a query read dataset.

Citation: Frank Aylward Introduction to read mapping. protocols.io

dx.doi.org/10.17504/protocols.io.piadkae

Published: 17 Apr 2018

Protocol

Ensure the appropriate tools are installed

Step 1.

First ensure that the following tools are installed and are in your PATH:

Bowtie 2 version 2.2.6

samtools Version: 0.1.19-96b5f2294a

bedtools v2.25.0

In the unix command line you can do this by typing "bowtie2", "samtools", and "bedtools" in the command line followed by the enter key.

The exact versions for bowtie2 and bedtools may not be critical, but try to get the same version of samtools since the command entries are different between different versions of that tool.

First we need to get a reference genome. In this case we will be working with a bacterium called Marinimicrobial UBA2153

Step 2.

First we need to get a reference genome to map reads against. We'll download the genome of Marinimicrobia UBA2153 here.

Download using the unix command wget:

wget

ftp://ftp.ncbi.nlm.nih.gov/genomes/all/GCA/002/328/885/GCA_002328885.1_ASM232888v1/GCA_002328885.1_ASM232888v1/gcA_002328880.1_ASM232888v1/gcA_002328880.1_ASM232888v1/gcA_002328880.1_ASM232888v1/gcA_002328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM2328880.1_ASM232880.1_ASM232880.1_ASM232880.1_ASM2328880.1_ASM23280.1_ASM23280.1_ASM2

And since the fasta file is compressed we will use the Unix tool gunzip to decompress it: gunzip GCA 002328885.1 ASM232888v1 genomic.fna.gz

Build bowtie2 reference

Step 3.

To use the read mapping tool bowtie2 we will need to first index the fasta file. This can be done using the command bowtie2-build. It will create several index files with different suffixes and the prefix that we give in the command after the fasta file (in this case UBA2153).

bowtie2-build GCA 002328885.1 ASM232888v1 genomic.fna UBA2153

Get the reads for mapping

Step 4.

Now we need to get the reads that we will use for mapping. We are going to download raw Illumina reads straight from the NCBI Sequence Read Archive (SRA) using the sra-toolkit. Since the sequence files are guite large we are only going to download a few to start with- in this case 10000.

fastq-dump -X 10000 --split-3 SRR5322088

Map the reads with bowtie2

Step 5.

bowtie2 -1 SRR5322088 1.fastg -2 SRR5322088 2.fastg -x UBA2153 -S mapping output.SAM

Now process the SAM file created by bowtie2 with samtools

Step 6.

samtools view -bS -F 4 mapping output.SAM > mapping output.bam

samtools sort mapping_output.bam mapping_output.sort samtools index mapping_output.sort.bam samtools idxstats mapping_output.sort.bam

The output of this last file should be a table with the number of reads that were found to have mapped to each reference sequence.